

Canon PG-510 / PG-512 Black Ink Cartridges
Canon CL-511 / CL-513 Colour Ink Cartridges

Refill Instructions

1. Read the instructions carefully.
2. Put some newspaper in case of any mess.
3. Remove the label on the top of the cartridge to see the filling holes.
4. For black cartridge; use the thumb drill to enlarge the filling hole in the middle of the cartridge. For color cartridge, also enlarge the three filling holes.
5. Fill the syringe with the required ink.

PG510 = 9ml, PG512 = 15ml, CL511 = 3ml (each colour), CL513 = 5ml (each colour)

Please note this is the cartridge max capacity and you may need less ink when refilling to avoid overfilling.

6. Start injecting the ink into the cartridge slowly.

Note: You may feel a slight resistance due to the sponge existing in the cartridge

7. The cartridge is full when the ink starts to overflow, stop injecting at this time and suck any excess ink back into the syringe.
8. Repeat the previous steps with the different color filling holes ensuring the syringe and needle are cleaned between colour changes.
9. Replace the label back and seal it with an adhesive tape.
10. Return the extra ink to the bottle.

Note: You can wash the syringe and dry it for future uses

11. Leave the cartridge for one night standing on a non-absorbent surface to make sure it doesn't leak and to give the ink the time to saturate the sponge.
12. Install the cartridge to the printer and run a cleaning cycle.

Note: For best results, once the cartridge is empty refill it immediately before the remains of the ink dries. 

Note: You will need to disable the ink level monitor on your printer by pressing the paper feed / reset button for 5 seconds. This will now deactivate any ink levels on your printer.

Poor printing will be due to dried ink on the print head, please use the cleaning fluid on the print head. See instructions.

